Operating manual Digital Temperature Controller DLTC 300

Digital Temperature Controller DLTC 300

www.redwavelabs.com

Contents

Introduction	3
Absolute Maximum Ratings	4
Mechanical Information	4
Connections	5
Software control	6
Connection	6
TEC setup	6
TEC Mode	7
TEC PID	7
Sensor	8
Graph Tab	
Warranty and returns	
Return procedure	

www.redwavelabs.com

Introduction

The DLTC 300 is a Digital Switched-mode Temperature Controller that combines high efficiency with full digital control of PWM (pulse width modulation).

The DLTC 300 has a full digital PID loop with additional optional external correction.

A set of analogue monitors ensures easy system integration. Settings are non-volatile: set up and forget.



Features	NTC and PTC thermistors as te Internal and External PI control Temperature stability 0.001 °C	·	
Applications	Laser, Detectors, Precision Inst	rument, OEM application	
Specifications	Parameter	Value	
Power	Single	+5 V to 30 V (Vdd)	
Input sensor	NTC, PTC thermistor	10, 50, 100, 250, 500, 1000, 1500 µA activation current	
	Compliance voltage	2 V	
Temperature	Internal Set point	Software selected	
	External Set point	0-5 V through 14 pin connector or software defined	
	Stability Over 1 hour	0.001 °C (with 20 K thermistor)	
Output	Bipolar current	+/-15 A	
	Current limit	Symmetrical. User defined between 0 and Imax	
	Compliance voltage	iance voltage 8V typical maximum value	
	P-I control Digital Controlled		
	Power	60 W maximum without heatsink	
	Security	Software programmable voltage and current limits	
Connectors	Power & TEC	Terminal blocks with M3 Screw	
	Digital Control	USB B	
	Analog Data	14 pin Molex MiniFit (mating part Molex 430251008)	
Monitor	Actual temperature	0-5V following sensor voltage	
	Set temperature	0-5V requested sensor voltage	
	Actual current	0-5V following current with 2.5V offset	
	Fault	Active high 5V fault line	
Dimensions (WxHxD)		89 x 89 x 23 mm	
Communication		USB 2.0	
Weight		240 g	
Storage Temp		-55 to 100 C	
Operating Temp		-40 to 85 C	


RedWave Labs Ltd keeps improving its products and therefore some specifications can vary.

Digital Temperature Controller DLTC 300

www.redwavelabs.com

Absolute Maximum Ratings

Symbol	Parameter	Ratings	Unit
V_{dd}	Supply voltage	+5 to 30	Volt
T _{op}	Operational Temperature	-40 to 85	Deg C
T _{st}	Storage Temperature	-55 to100	Deg C



Parameter	Value	Unit
Length	89(3.5)	mm (Inch)
Width	89(3.5)	mm (Inch)
Height	23(0.9)	mm (Inch)
Total Height Including sockets	23(0.9)	mm (Inch)
Weight	240	Gram

www.redwavelabs.com

Connections

Power in and Output to TEC are by screw terminals these accept a 3mm screw 5mm long which are supplied. The wire used must be suitable to handle the current required without excessive voltage drop, which could prevent the device from delivering its maximum output current. An isolated supply is recommended for this device if the analog controls are to be used, as no power supply current must flow through the control ground pin as this would cause inaccurate control or readings

The device should be bolted to a heatsink of suitable size to keep the base temperature below 85C

The communication is via a USB "B" style connector which establishes a virtual serial connection, the protocol settings should be left unchanged. This is identified as a USB serial device in windows device manager which will also show the port number allocated to the device.

The analog data port is a 10-way Molex Micro-Fit 3.0

pin				cable core
1	SENSOR -ve	Negative connection for the sensor		2 way Blue
2	TEC CURRENT DISABLE	External TEC current disable Pin,	A logic high disables the TEC power supply	8 way Violet
3	SET TEC CURRENT EXT	Set TEC current In external control mode	The sensitivity is 6A/V with an offset of 2.5V and range of 0V to +5V	8 way Blue
4	MAX CURRENT STATUS	TEC current goes too high or when TEC is open or short circuit	logic high when a fault condition is present	8 way Red
5	MONITOR SET TEMPERATURE	Represents required temperature	Follows the parameters of the selected sensor	8 way Yellow
6	SENSOR +ve	Positive connection for the sensor		2 way Red
7	MONITOR TEC CURRENT	Represents actual TEC Current	The sensitivity is $6A/V$ with an offset of 2.5V and range of 0V to $+5V$	8 way Brown
8	SET TEC TEMPERATURE	Demand temperature for TEC in "TEC_MODE_EXT_TEMP_C" mode	Follows the parameters of the selected sensor	8 way Black
9	MONITOR TEMPERATURE	Represents current temperature	Follows the parameters of the selected sensor	8 way White
10	Agnd	Ground for Analogue signals.	This pin must not be connected to the Power Ground (Pin1).	8 way Green

The connector Molex part No. 0430251008 Digi-key part WM16255-ND, Socket contacts Molex Part No.0430300009 Digi-key part WM1839-ND

Digital Temperature Controller DLTC 300

www.redwavelabs.com

Software control

Connection

The USB port establishes a virtual serial connection the protocol settings must be left unchanged. The Redwave SCPI Term software can be used to set up and manage the device. To connect the device, enter "COMxx" in the TCP/IP port box where xx is the com port number allocated by windows, this can be found in device Manager. Once connected click on the Refresh button in the TrgtSys tab the indicators will load with some basic data from the device

WV SCPI Term Tool v6001.6.1	- 0	×	
CP/IP Port SCPI Status			
Close COM20 SYST:ERR:ALL? 0,"No error"	Auto check Auto c cmd success Auto c		
Scpi99 SYSTem Trgt Sys Trgt Uar Log VT100 FILE LOG Graph TEC Sensor Pid PWR Pid Tune			
Access control to system data	Refresh	x Device Manager − □ File Action View Help	×
Hardware Information			
TRGT::REBOOT TRGT::REBOOT TRGT::REBOOT SOF	ग 💌	V 🗄 LAPTOP-JDEANS	
Hardware Version		> 10 Audio inputs and outputs	
TRGT_HW_DLTC300 Version TRGT_HW_VER_NONE	•	> 3 bluetooth	
CNTs 0 LDs 0 PDs 0 PWRs 1 RFs 0 SENSs 1 TECs 1		> @ Cameras	
Store Infromation Interval		> Computer	
TRGT:LOG:INTERVAL 600 TRGT:TIME:LIFE 20 TRGT:TIME:LIFE	6759	See ControlVault Device Disk drives	
Features		> 🥃 Display adapters	
TRGT::FEATURE 0x01 V LCD		> III Firmware	
		Ample Human Interface Devices Ample Interface Devices Ample Interface Devices	
Target PCB temperature		v 🐙 Jungo Connectivity	
TRGT:T:LIMIT 85.0 TRGT:T? 30.0		WinDriver	
MAC address Monitors		> 🥅 Keyboards	
TRGT:MACADDRESS 00000000000 TRGT:VCC? 22.5029		> I Memory technology devices	
		Mice and other pointing devices	
Product Name Product Name		> Imp Monitors > Imp Network adapters	
TRGT:NAME DLTC300 TRGT:TITLE undefined		 Vetwork adapters Vetwork adapters Vetwork adapters 	
12C/SMBus status		V Ports (COM & LPT)	
TRGT:SMBUS? RST 0 PEC 0 Time 0 Addr 0 Data 0		USB Serial Device (COM20)	
		> 🛱 Print queues	
WatchDog		> 🖻 Printers	
TRGT:WATCHDOG enabled 1 reset detected 0		> Processors	
		N 🕼 Security devices	

TEC setup

Click on the TEC Tab followed by refresh in the TEC screen, the default TEC settings will be shown. The maximum current and voltage settings should be set for the TEC being controlled. To adjust settings, enter the value in the text box then click on the adjacent button to load the new value. The required TEC operating mode may be selected

Close COM20	SYST:ER	R:ALL? 0,"No error"		Auto check and success and err co
999 SYSTem Trgt Sys Trgt U	er Log VT 100 FILE LOG	Graph TEC Sensor Pid PW	R Pid Tune	
TEC TEC_1		•		Refresh
Current				
TEC:L:MAX	(-min A) -15.0	(+max A) 15.0		
TEC:[:LIMIT	(-min A) -15.0	(+max A) 15.0		
TEC:I[:SET?]	(A) 0.1	TEC:IP	(A) 0.0	
Current Slope				
TEC:1:SLOPE:MAX	(min A/s) 1.0	(max A/s) 5.0		
TEC:1:SLOPE[:SET?]	(A/s) 5.0	TEC:1:SLOPE?	(A/s) 5.0	
Voltage				
TEC:V:MAX	(-min V) -10.0	(+max V) 10.0		
TEC:VILIMIT	(-min V) -10.0	(+max V) 10.0		
TEC:V[:SET7]	(1) 2.0	TEC:V?	(v) 0.0	
TEC				
TEC:MODE	Mode TEC_MODE	INT_TEMPC -		
TEC:OUTPUT	Output MOD_ON			
TEC:PID	Kp 1.94771	10.385915	Kd 2.45753	
TEC:PID:RATE	(s) 0.0			
TEC:FAULT?	Mask 0			
Temperature				
TEC:T:MAX	(min C) -10.0	(max C) 60.0		
TEC:T[:SET7]	(c) 20.0	TEC:T?	(C) 24.4757	

www.redwavelabs.com

TEC Mode

TEC mode is elected by the drop-down selection there are four modes

TE	C				
	TEC:MODE	Mode	TEC_MODE_INT_TEMPC	-	
	TEC:OUTPUT	Output	TEC_MODE_INT_TEMPC TEC_MODE_EXT_TEMPC		
	TEC:PID	Kp 1.94	TEC_MODE_EXT_I TEC_MODE_EXT_I TEC_MODE_INT_I		
	TEC:PID:RATE	(s) 0.0			

TEC_MODE_INT_TEMPC

The TEC is held at the temperature set in the Temperature section, click the TEC:T[SET?] button to set the Temperature entered

Te	mperature				
	TEC:T:MAX	(min C) -10.0	(max C) 60.0		
				(0) 04 4757	
	TEC:T[:SET?]	(C) 20.0	TEC:T?	(C) 24.4757	

TEC_MODE_EXT_TEMPC

The TEC is held at the temperature set by the voltage on the SET TEC TEMPERATURE input pin. The sensor thermistor voltage will be the same that on this pin.

TEC_MODE_EXT_I

The TEC current is fixed and set buy the voltage on the SET TEC CURRENT EXT. The sensitivity is 6A/V with an offset of 2.5V and range of 0V to +5V. So 2.5V would signal a current of 0A, 0.5V would be -12A, and 4.5V would be +12A

TEC_MODE_INT_I

The TEC current is fixed and set by the entry in the TEC:I box in the Current section, click the TEC:I[SET?] button to set the current entered

Current		
TEC:I:MAX	(-min A) -15.0	(+max A) 15.0
TEC:I:LIMIT	(-min A) -15.0	(+max A) 15.0
TEC:I[:SET?]	(A) 0.1	TEC:1? (A) 0.0


TEC PID

TEC			
TEC:MODE	Mode TEC_MODE_INT_TE	MPC	
TEC:OUTPUT	Output MOD_ON	•	
TEC:PID	Кр 1.94771	Ki 0.385915	Kd 2.45753
TEC:PID:RATE	(s) 0.0		
TEC:FAULT?	Mask 0		

If know the TEC PID parameters may be set in the TEC:PID boxes pressing the TEC:PID button will enter the parameters in to the unit. If the parameters are unknown then the PID tune facility may be used

Digital Temperature Controller DLTC 300

www.redwavelabs.com



Set a suitable target temperature click the START button the temperature can be observed cycling twice, in the graph window, the PID information will appear in the output window Click Set Pid Values to set the PID

Sensor

Click on the Sensor Tab followed by refresh in the sensor screen, the default sensor settings will be shown.

WW SCPI Term Tool v6001.6.1			-	□ X
TCP/IP Port Close COM20	SCPI Status SYST:ERR:ALL?	0, "No error"	Auto check cmd success	Auto clear err code
Scpi99 SYSTem Trgt Sys Trgt Usr SENSOR SENS_1	Log VT100 FILE LOG Graph	TEC Sensor Pid PWR Pid Tune	a	resh
SENSOR:TYPE	Type SENSOR_THERMISTOR	•		
SENSOR:CONST	Ro 20000.0	A 0.000886165	C 0.0	
SENSOR:IEXC[:SET?]	(uA) 100.0	SENSOR:IEXC? (uA) 100.0	
SENSOR:INFO?	Res Ohm 20178.1	uA 100.0	C 24.804	
Temperature History Range RANGE				
SENSOR:HISTORY? SENSOR:HISTORY:INDEX?	Index 13013	time 946697566 0	24.804	
SENSOR:HISTORY:INFO?	Rd 12966	Wr 13014		

8

www.redwavelabs.com

Sensor:Type

Currently only type SENSOR_THERMISTOR is supported. Selection of any other type will result in an error

Sensor:Const

The parameters Ro, A, B, & C from the thermistor data sheet should be entered here

Sensor:IEXEC[:SET]

The data entered in this box sets the sensor current in uA, values of 10uA, 50uA 100uA 500uA, 1mA or 1.5mA are currently supported, any other values will be adjusted to the lower supported value


Clicking on the SENSOR:INFO box will show the current sensor conditions

Sensor selection

Be aware that the maximum sensor voltage is the 3.3V supply rail so a sensor and sensor current must be chosen that will have voltage drop in the range of 0.5 to 3V in the temperature range of interest

Graph Tab

Clicking on the Graph tag allows graphical monitoring of the TEC temperature



Certification

RedWave Labs Ltd certifies that: i) the parts and/or materials were produced in conformance with all contractually applicable Government and/or Buyer's specification as referenced in, or furnished with, the above purchase order and ii) all processes required in the production of these parts and/or materials are listed and were performed by a facility or by personnel specifically approved or certified by the seller's cognizant government quality control agency when such approval or certification is required by an applicable specification. RedWave Labs products are not authorized for use in safety-critical applications (such as life support) where a failure of the product would reasonably be expected to cause severe personal injury or death, unless officers of the parties have executed an agreement specifically governing such use of the products.

www.redwavelabs.com

Warranty and returns

Digital Temperature Controllers are warranted against defects in materials and workmanship for a period of 180 days from date of shipment. During the warranty period RedWave Labs Ltd will replace or repair products which prove to be defective or damaged. Our warranty shall not apply to defects or damages resulting from: i) misuse of the product or ii) operation beyond specifications detailed in the current manual.

Return procedure

Customer must obtain a valid RMA number by contacting RedWave Labs prior to the return. In all cases the customer is responsible for duty fees incurred on all received shipments and on all international returns for both warranty and non-warranty items; the customer is responsible for any duties, brokers fees or freight charges deemed chargeable to RedWave Labs Ltd.